



Washing Process	Water Level	Water Temperature	Detergent	Time in minutes
Shake out in tumble dryer	/	/	/	2-4 Minutes
Rinse	High	Cold	/	2-3 Minutes
Water Release	/	/	/	1-2 Minutes
Washing	High	Cold up to 60 °C	Concentrated non-ionic, non-alkaline detergent	5-10 Minutes
Water Release	/	/	/	1-2 Minutes
Spin-Drying (SLOW)	/	/	/	1-2 Minutes
Rinse	High	Cold up to 60 °C	/	2 Minutes
Water Release	/	/	/	1-2 Minutes
Rinse	High	Cold up to 60 °C	/	2 Minutes
Release and Tumbling, slowly in reverse spin	/	/	/	2-3 Minutes
Forward Spin-Drying (SLOW)	/	/	/	2-3 Minutes
Forward Spin-Drying (FAST)	/	/	/	2-4 Minutes
Tumble drying	/	Up to max. 70 °C	/	5-7 Minutes
Cool Down Tumbling	/	Without heat	/	5-7 Minutes

Store mats flat until they are cooled down